

Operating Instructions



Sno Cone

Note: This machine will shave 300-500 pounds of ice per hour. 100 pounds of ice equals 300 servings, and 5 pounds of ice equals 15 servings.

1. Place this machine on a sturdy surface.
2. Plug this unit into a dedicated 15 amp outlet.
3. Fill the gooseneck with ice cubes or block ice. If using block ice, break it into 3" or 4" pieces. Fill to about an inch or so from the top. (The larger the piece of ice, the better the snow.) Turn on the motor and hold the red shave button.
4. Push the handle down so the ice presses against the cutter head. Even firm pressure is all that is required. You may need to relieve the pressure two or three times on the way down.

Too much pressure on the pusher handle will make the snow come out coarse; too little pressure makes the ice mushy.

5. Scoop the ice into a cup and add the flavor of your choice. Enjoy.

Do not let metal get into the gooseneck, or you will ruin the blades.

Never put your hands into the gooseneck while the machine is running; unplug first.

Never leave this machine unattended while plugged in.

**For any questions or concerns, be sure to contact us immediately.
Thank you for your business!**

1155 Route 9
Wappingers Falls, NY
(845) 298-0011



1 Precision Road
Danbury, CT
(203) 744-2295